### **Installation Manual**



# ZW39 Z-Wave Smart Plug (Dimmer)

#### **Specifications:**

Power: 120VAC, 60Hz Loading: 500W Frequency: 908.42MHz FCC ID: OXGZW36 IC: 10460A-ZW36

#### Adding Device To Z-Wave Network for QR CODE



Scan here for SmartStar inclusion

Note: DSK Code can be found on the packaging box.

Do not remove or damage them.

#### INTRODUCTION

The EVA LOGIK ZW39 is a Z-Wave enabled 500W receptacle designed for most residential lighting and applications. It's compatible with LED, halogen, incandescent. The ZW39 fully works with the Fibaro, Smartthings, Wink hub as well as all other certified Z-Wave controllers.

# Manual / Program button

Press 1x: Manual ON/OFF Press 2x: Scene 1 Press 3x: Add mode(bule light blinking)/Remove mode(purple light blinking).

Smart Outlet

This outlet can remotely turn On/Off the connected device.

Plug the light you want to control into the Z-Wave Smart plug controlled outlet.

NOTE: Plug directly into outlet, do not use with extension cords.



#### Note:

Your device may need to be within 100 feet of the controller to be included. If so, include the device to the network within 10 feet of the controller and relocate it to the desired position in your home. Be sure to refresh the network if the device is included in this manner.







- 1. Quickly press the button 5 times (blue indicator flashes slowly), and the connected bulb is automatically adjusted to the minimum brightness currently.
- 2. Hold the button to adjust the brightness of the connected bulb, select the appropriate brightness and set it to the minimum brightness.
- Quickly press the button 5 times to confirm the minimum brightness. Exit setting after the setting is completed (indicator flashes 3 times).

#### Maximum brightness setting

- 1. Quickly press the button 10 times (blue indicator flashes slowly), and the connected bulb automatically adjusts to the maximum brightness currently.
- 2. Hold the button to adjust the brightness of the connected bulb, select the appropriate brightness and set it to the maximum brightness.
- 3. Quickly press the button 10 times to confirm the maximum brightness. Exit setting after the setting is completed (the indicator flashes 3 times).
- Note: If no confirm in step 3, the setting mode will be exited after 10s and the adjusted bright ness value will not be saved.

### **Z-Wave Network Configuration**



#### Adding Device To Z-Wave Network

- Follow the instructions for your Z-Wave certified controller to add a device to the Z-Wave network.
- Once the controller is ready to add your device, press the manual/program button(A) on the smart dimmer 3 times quickly. The white LED will blink quickly.

**Auto-add mode:** LED will blink within 30 seconds after first plugged in.

Now, you have complete control to turn your fixture ON/OFF or set dim levels according to groups, scenes, schedules and interactive automation programmed by your controller. If your Z-Wave certified controller features remote access, you can control your fixture from your mobile devices.

#### Again:

If you have issues with pairing/including, please move the device as close as possible to the hub and try again--you can move to your final location when completed.

#### Note:

If the manual button(A) doesn't light up after pressed 3 times, please reset the device: click the button 2 times quickly then hold for at least 10 seconds. This operation could be done when manual control is functional--single press can turn on/off the lamp.

### To Remove The Device

- Follow the instructions for your Z-Wave certified controller to remove a device from the Z-Wave network.
- Once the controller is ready to remove your device, press the manual/program button(A) on the smart dimmer 3 times quickly.

# To Return The Device To Factory Defaults:

Manual: Click the button 2 times quickly then hold for at least 10 seconds

**Host reset:** Remove it from the host connection and the device will factory reset

## **Association Group:**

Group 1 supports 1 node ID. Group 2 Supports up to 5 node IDs.

Association group\_1: Z-Wave Plus Lifeline Association Group 2: Send Basic Set ON/OFF